

# Technical information VitoMat I Manual Filling Machine



The ColorMatic VitoMat filling machines allow ColorMatic pre-fill spray paint cans (already containing propellant and specific additives) to be filled with individual paints. There are three different VitoMat filling machines to choose from, each offering advantages for different needs. All machines fill both 400ml and 150ml cans.

## Application:

VitoMat I is ideal for filling small quantities.

## Quality and properties      Physical and chemical data

- Robust, stable machine, suitable for filling micro and small quantities
- All-important functions clear to see and easy to read
- Portable, removable piston, which fits the cylinder
- Compatible with CleanJector
- No power supply required
- Mobile and flexible
- Very simple operation
- Suitable for filling 400ml and 150ml cans
- Suitable for filling 1K and 2K coating qualities
- Suitable for water-and solvent-based coats
- Fast colour change
- Very good value for money
- **Description:** Exterior: Case made of stainless high-grade steel with door, operation controls and control display, base plate and filling lever. Interior: Mobile lifting device with stop plate, cylinder as paint receptacle and intended holding device, mobile piston and adapter for filling
- **Measurements:** 32 x 25 x 75 cm
- **Capacity:** ca. 20 cans/ h (without colour change, depends on the viscosity of the paint)
- **Max. filling viscosity:** 300 s/DIN 4 mm
- **Life:** Long working life since there is almost no wear and tear

## Disposal and labelling

**Disposal:** Only the completely emptied cans should be put into the recycling skip or appropriate container for reclaimable refuse. Cans which are not empty should be disposed off as "special refuse".

**Marking/Labelling:** All products made by European Aerosols comply with the actual labelling regulations according to Preparation Guideline 1999/45/EG. All aerosols correspond to TRGS 200 and TRG 300 as well as to aerosol guideline 75/324/EEC in the actually valid version.

## Using instructions

**Before use, carefully read and observe the warning texts on the label!**

- Easy filling process
- For detailed instructions, please refer to the attached manual
- For professional use only
- Wear appropriate protection goggles and gloves

## **Hints concerning filling**

If you use the intended base plate to bolt the VitoMat II firmly to the ground, working will be so much easier. The adjustable pedestals can be used to quickly stabilise the device.

## **Order information**

## **Disclaimer of liability**

This application-technological information is given to the best of our knowledge. The notes mentioned herein are, however, non-binding and do not exempt you from own tests to see whether the products supplied by us are suitable for your special application. The use and processing is beyond our control and therefore exclusively in the responsibility of the user. European Aerosols is let off the liability, unless the liability-based incident is caused by a fault incurred to European Aerosols.

As of October 16, 2013

This release replaces all eventually earlier issued versions.

Print date: 16.08.2026

European Aerosols | Wolfraamweg 2 | 8471 XC Wolvega | NL | [info-nl@european-aerosols.com](mailto:info-nl@european-aerosols.com)